LivePremier [™]series: the LUT-based color processing and how to configure it

Analog Way Worldwide Europe & Africa: +33 (0)1 81 89 08 60 Middle East: +971 4 25 33 818 The Americas: +1 212 269 1902 Asia Pacific: +852 6882 7140 www.analogway.com

XX ANALOG WAY®

Introduction

In the last few years, the color management has dramatically evolved with new standards such as wide color gamut (BT. 2020) and high dynamic range (HDR) for even more impressive and accurate colors.

Most specifications of presentation switchers indicate they support wide color gamut and/or HDR but forget to explain that this only works in homogeneous workflows: all the sources and displays must use the same color space and dynamic range.

However, in real life, it is not unusual to mix contents with different color spaces (BT.709 and BT.2020) and/or different dynamic ranges (for instance, an HDR video mixed with an SDR presentations and spreadsheets). The simultaneous use of HDR display for main screens and SDR displays for auxiliary screens also becomes more and more frequent.

Another key point for some demanding applications is the ability to help the color calibrating of displays with advanced color corrections, that common settings (R/G/B levels, brightness, contrast and gamma) can't achieve.

The LivePremier series with firmware v3.0 can now achieve all these conversions and corrections thanks to its brand-new color processing based on 3D look-up tables (LUT). This new architecture also offers a new chroma keying algorithm for even better results and ease of use.

After a few reminders, this document is intended to give a crucial understanding of how this new color processing works and how to configure it properly, as if not, this may lead to the opposite effect of the expected one.

ANALOG WAY®

Contents

1.	Basic knowledge7					
1.1.	. Gamuts					
1.2.	. RGB and YCbCr encodings8					
1.3.	Dyna	mic Range9				
	1.3.1.	Standard Dynamic Range9				
	1.3.2.	High Dynamic Range9				
	1.3.2.1.	HDR10 Media Profile9				
	1.3.2.2.	Hybrid Log-Gamma9				
1.4.	3D lo	ok-up tables				
1.5.	Inter	faces				
	1.5.1.	DisplayPort13				
	1.5.2.	HDMI13				
	1.5.3.	SDI13				
	1.5.4.	ST2110				
	1.5.5.	NDI14				
	1.5.6.	SDVoE				
2.	Color co	onversions and corrections15				
2.1.	Why	is conversion between BT.709 and BT.2020 needed?15				
2.2.	Why	is SDR/HDR conversion needed?16				
2.3.	3. Why is Color Correction needed?					
2.4.	Color	r Keying				
3.	The Live	ePremier Series and its 3D LUT color processing18				
3.1.	Archi	itecture				
3.2.	Bene	fits				
4.	Configu	ring the color processing				
4.1.	Confi	iguring input EDIDs				
4.2.	Confi	iguring the internal color processing21				
4.3.	Impo	rting custom LUTs				
	4.3.1.	Importing conversion LUTs				
	4.3.2.	Importing correction LUTs				
	4.3.3.	Importing CremaTTe 3D LUTs24				
4.4.	Confi	iguring the conversions for inputs				
	4.4.1.	Configuring the inputs with an SDR internal processing				
	4.4.2.	Configuring the inputs with an HDR10 internal processing				
	4.4.3.	Configuring the inputs with an HLG BBC internal processing				
4.5.	Confi	iguring the color correction LUT for inputs				

MANALOG WAY®

APPLICATION NOTE

4.6.	Confi	Configuring the CremaTTe 3D LUT for inputs				
4.7.	Confi	Configuring the conversions for outputs				
	4.7.1.	Configuring the outputs with an SDR internal processing	31			
	4.7.1.	Configuring the outputs with an HDR10 internal processing	31			
	4.7.2.	Configuring the outputs with an HLG BBC internal processing	32			
4.8.	Confi	guring the color correction LUT for outputs	33			
4.9.	Configuring an output connected to a DPH104					

Figures

Figure 1:CIE 1931 chromaticity diagram with SDTV, HDTV and UDTV gamuts	7
Figure 2: Common YCbCr chroma subsampling schemes	8
Figure 3: HLG transfer function vs SDR transfer function	. 10
Figure 4: Example of a 9x9x9 RGB LUT	. 11
Figure 5: Trilinear interpolation (left) VS Tetrahedral interpolation (right)	. 12
Figure 6: SDVoE with HDMI interfaces	. 14
Figure 7: Non-conversion from ITU-R BT.709 to ITU-RBT.2020	. 15
Figure 8: Non-conversion from ITU-RBT.2020 to ITU-R BT.709	. 15
Figure 9: Non-conversion from SDR (left) to HDR10 (right) leading to burned colors	. 16
Figure 10: Non-conversion from HDR10 (left) to HLG (right) leading to dimmed colors	. 16
Figure 11: Dynamic Range et Color Space conversions in the LivePremier Series	. 18
Figure 12: Example of heterogeneous workflow with a basic switcher	. 19
Figure 13: Example of heterogeneous workflow range setup with a LivePremier system	. 19
Figure 14: Default EDIDs for HDR support	. 20
Figure 15: Status of Input 9 receiving an HDR10 1000nits content	. 20
Figure 16: Example of a Color Processing configuration for HDR10	.21
Figure 17: Example of source statuses	. 21
Figure 18: Hovering over an empty slot	. 22
Figure 19: Upload form for a conversion LUT	. 22
Figure 20: Slot of a conversion LUT after upload	. 23
Figure 21: Upload form for a correction LUT	. 23
Figure 22: Slot of a correction LUT after upload	. 23
Figure 23: Upload form for a CremaTTe 3D LUT	. 24
Figure 24: Slot of a CremaTTe 3D LUT after Upload	. 24
Figure 25: Forcing the dynamic range of an input	. 25
Figure 26: Selecting an input custom conversion LUT	. 25
Figure 27: Standard manual color correction (left) vs LUT-based color correction (right)	. 28
Figure 28: Connection wizard of AW CremaTTe 3D	. 29
Figure 29: LUT selection for input keying	. 29
Figure 30: Forcing the color space and dynamic range of an output	. 30
Figure 31: Selecting an output custom conversion LUT	. 30
Figure 32: Standard manual color correction (left) vs LUT-based color correction (right)	. 33
Figure 33: No link between displays' EDIDs and DPH104's EDID	. 34

🔊 ANALOG WAY®

Reference List

- CTA-861-G (11/2016) A DTV Profile for Uncompressed High Speed Digital Interfaces
- ITU-R BT.601-7 (03/2011) Studio encoding parameters of digital television for standard 4:3 and wide-screen 16:9 aspect ratios
- ITU-R BT.709-6 (6/2015) Parameter values for the HDTV standards for production and international programme exchange
- ITU-R BT.2020-2 (10/2015) Parameter values for ultra-high definition television systems for production and international programme exchange
- ITU-R BT.2100-0 (07/2016) Image parameter values for high dynamic range television for use in production and international programme exchange
- ITU-R BT.2390-9 (03/2021) High dynamic range television for production and international programme exchange
- ITU-R BT.2408-4 (03/2021) Guidance for operational practices in HDR television production
- SMPTE ST 425-1:2017 Source Image and Ancillary Data Mapping for the 3Gb/s Serial Interface
- SMPTE ST 2081-10:2018 2160-line and 1080-line Source Image and Ancillary Data Mapping for 6G-SDI
- SMPTE ST 2082-10:2018 2160-line and 1080-line Source Image and Ancillary Data Mapping for 12G-SDI
- SMPTE ST 2084:2014 High Dynamic Range Electro-Optical Transfer Function of Mastering Reference Displays
- SMPTE ST 2086:2018 Mastering Display Color Volume Metadata Supporting High Luminance and Wide Color Gamut Images
- SMPTE ST 2110-20-2017 Professional Media Over Managed IP Networks: Uncompressed Active Video
- VESA DisplayPort (DP) Standard: version 1.2, 1.3 and 1.4
- 3D LUT interpolation JD Vandenberg August 28th 2019
- Cube LUT Specification Version 1.0, Adobe September 2013

1. Basic knowledge

1.1. Gamuts

The gamut is the whole range of colors managed by a device. Computer graphics and video systems handle a subset of the color spectrum the human eye can see. Models of this spectrum were created in 1931 by the International Commission on Illumination and are known as CIE 1931 color spaces (CIE is the abbreviation of French name "Commission Internationale de l'Eclairage", "International Commission on Illumination" in English).

- The color space of SDTV system was specified in **ITU-R BT.601** and covers 35% of the CIE 1931 color space.
- The color space of HDTV system was specified in **ITU-R BT.709**. It is very close to the color space of ITU-R BT.601 and covers 35.9% of the CIE 1931 color space.
- The color space of UHDTV system is specified in **ITU-R BT.2020** and covers 75.8% of the CIE 1931 color space. It is called *Wide Color Gamut*.



Figure 1:CIE 1931 chromaticity diagram with SDTV, HDTV and UDTV gamuts

IMPORTANT: there are also other color spaces such as DCI-P3 or sRGB with gamuts larger than ITU-R BT.709 but smaller than ITU-R BT.2020. They are currently not supported by the LivePremier series.

1.2. RGB and YCbCr encodings

The three ITU-R (BT.601, BT.709 and BT.2020) specify the digital representations of the colors. They define RGB (Red-Green-Blue) and YCbCr (Luma/Blue Chroma/Red Chroma) encodings and the conversions between these two encodings.

IMPORTANT: These encodings are specific to each of these ITU-R. It means that, given a bit depth, a color of the CIE 1931 with given X and Y coordinates won't have the same RGB or YCbCr values.

If RGB seems to be the more intuitive way to encode a color, YCbCr is very interesting for it has interesting properties deeply related to human vision. As human eye is more sensitive to luma changes, it is possible to subsample the chroma components of an image/video signal to save space/bandwidth. It is also possible to apply filters (low-pass, sharpness...) on the luma component only and therefore, save resources (computation time and/or hardware resources).

Usually, a Jx2 pixel area is used to represent the chroma subsampling scheme and the "J:a:b" notation is used:

- "J" the number of luma information per line. It is usually 4.
- "a" the number of chroma information on the first line
- "b" the number of chroma information on the second line. When b=0, the chromainformation of the first line is used.



Figure 2: Common YCbCr chroma subsampling schemes

1.3. Dynamic Range

1.3.1. Standard Dynamic Range

SDR video is a technology that uses gamma curves to convert light intensity to electrical signal, and vice versa. Based on the limitations of CRT displays, the maximum luminance of video display is 100 cd/m^2 (or nits).

The opto-electronic transfer function (OETF) is specified for each color space: ITU-R BT.601, ITU-R BT.709 and ITU-R BT.2020.

The electro-optical transfer function (EOTF) is specified in ITU-R BT.BT.1886.

1.3.2. High Dynamic Range

There are many HDR standards, but this chapter mainly focuses on the two standards specified in the ITU-R BT.2100 and supported by the LivePremier series:

- Perceptual Quantizer (PQ)
- Hybrid Log-Gamma (*HLG*)

IMPORTANT: HDR is often deeply tied to ITU-R BT.2020 and 10bit color depth. However, it can be used with ITU-R BT.709, 8-bit color depth and lessened results...

1.3.2.1. HDR10 Media Profile

Commonly called *HDR10*, it was announced by the CTA (Consumer Technology Association, formerly CEA Consumer Electronics Association) in 2015. HDR10 uses:

- the Wide Color Gamut specified in ITU-R BT.2020
- a **10-bit** color depth (30 bits per pixel)
- the *PQ* transfer function specified in the *SMPTE ST 2084*. It is a nonlinear electrooptical transfer function (EOTF) supporting a luminance range of 0-10000cd/m² (or nits).
- static metadata to send information about the data content. These metadata are specified in *SMPTE ST 2086* and *CTA-861-G*. Among the metadata information, two of them are important to know:
 - Maximum Frame-Average Light Level (*MaxFALL*): contains the highest frameaverage light level in of whole content.
 - Maximum Content Light Level (*MaxCLL*): contains the light level of the brightest pixel in the whole content.

1.3.2.2. Hybrid Log-Gamma

The HLG profile was jointly developed by the **BBC** (British Broadcasting Corporation) and the **NHK** (Nippon Hōsō Kyōkai, Japan Broadcasting Corporation in English).

It is a backwards-compatible HDR standard as it is still compatible with existing transmissions standards regarding SDR.

HLG uses:

- the Wide Color Gamut specified in ITU-R BT.2020
- a bit depth of *10 bits* (30 bits per pixel)
- a nonlinear transfer function composed of:
 - A *gamma* curve in its lower half of signal values,
 - A *logarithmic* curve in its upper part.

APPLICATION NOTE

NANALOG WAY®



Figure 3: HLG transfer function vs SDR transfer function

HLG does not require metadata except the one specifying HLG profile is used.

1.4. 3D look-up tables

Converting a value to another one using a mathematical formula can consume a lot of computation time, especially when the conversion is not linear. That may be a huge problem for real-time application. A common solution is to use a table of precomputed values to map the input value: it just uses memory and dramatically reduces the computation time. A 3D look-up table (3D LUT) is a table that uses an input triplet to compute an output value.

Therefore, 3D LUTs are very well adapted to map color spaces to others. But mapping each input color to its output color would cost too much memory to store and parse (for a 10-bit signal, more than 4GB). Therefore, the look-up table is subsampled.



Figure 4: Example of a 9x9x9 RGB LUT

To find the output color of an input color that doesn't exist in the table, an interpolation algorithm is used.

There are different types of algorithms: from basic trilinear interpolation, using the 8 vertices of the cube containing the input triplet, to tetrahedral interpolation based on tetrahedrons. This latest solution is far more accurate as it only uses the four closest vertices (a tetrahedron):

- It limits the influence of the others, especially in areas where the output colors have high-dynamic variations.
- It allows to reduce the size of the LUTs.

🔊 ANALOG WAY®

APPLICATION NOTE



Figure 5: Trilinear interpolation (left) VS Tetrahedral interpolation (right)

LUTs can be mathematically combined and interpolated to create a single LUT if the consistency of their input and output data types is respected. This property is very important when several conversions/corrections must be achieved simultaneously: in our case color space conversion, dynamic range conversion and color correction.

For best results, the LivePremier series uses 33x33x33 10-bit 3D LUTs with a tetrahedral interpolation.

1.5. Interfaces

1.5.1. DisplayPort

ITU-R BT.2020 support is specified in version 1.3 of DisplayPort and HDR10 support is specified in version 1.4 of DisplayPort.

These features are integrated in the DPCD (DisplayPort Configuration Data).

IMPORTANT: It is possible to implement a DisplayPort 1.2 interface with a DPCD version 1.4 and therefore to support ITU-R BT.2020 and HDR10 with static metadata. But it cannot be called DP1.4 as its bandwidth is limited to 21.6Gbits/s (17.28Gbits/s bandwidth available) and does not support other features such as DSC (Display Stream Compression).

Consequently, the LivePremier series has DP1.2 interfaces but **does support ITU-R BT.2020 and HDR10** up to 4K 60Hz 10bit 4:4:4.

1.5.2. HDMI

HDMI 2.0 supports the color space of *ITU-R BT.2020*. But support of HDR with static metadata only comes in version 2.0a. This version included the support of HDR10. Later, HLG was added in specification of **HDMI 2.0b**.

IMPORTANT: Due to HDMI 2.0's 18Gbits/s bandwidth, supporting both 4K/UHDTV and a 10bit data format needed for HDR implies to either subsample the chroma data or reduce the frame rate:

- 3840 x 2160 @ 50/60Hz 10bit 4:2:2 or 4:2:0
- o 3840 x 2160 @ 25/30Hz 10bit 4:4:4

The LivePremier series integrates HDMI 2.0b.

1.5.3. SDI

After several evolutions of the standards, HDR (HDR10 and HLG) and ITU-R BT2020 are supported by:

- 3G-SDI (SMPTE ST 425-1:2017)
- 6G-SDI (SMPTE ST 2081-10:2018)
- 12G-SDI (SMPTE ST 2082-10:2018).

The HDR profile is available in the payload identifier's byte 2 specifying the transfer characteristics.

The ITU-R BT.2020 profile is available in the payload identifier's byte 3 specifying the colorimetry.

The LivePremier series supports ITU-R BT 2020 and HDR for 3G-SDI, 6G-SDI and 12G-SDI.

1.5.4. ST2110

ST 2110 interfaces support HDR. According to SMPTE 2110-20:2017, it is possible to specify in the Media Type Parameters:

- the color space in the Colorimetry parameter
- the dynamic range in the Transfer Characteristic System parameter

MANALOG WAY®

1.5.5. NDI

NDI supports HDR since version 4.0 (2019-11).

The LivePremier series implementation of NDI 5 only support SDR with 8 bits per components.

1.5.6. SDVoE

SDVoE Tx/Rx are implemented with HDMI 2.0 interfaces. It means that they send and receive HDMI data and metadata over an IP network. Therefore, SDVoE natively supports HDR.



Figure 6: SDVoE with HDMI interfaces

2. Color conversions and corrections

2.1. Why is conversion between BT.709 and BT.2020 needed?

A color of the CIE 1931 color space encoded in ITU-R BT.709 doesn't have the same RGB or YCbCr values in ITU-R BT.2020. And reciprocally, the same values in ITU-R BT.709 and ITU-R BT.2020 may represent the same color (X/Y values) in the CIE 1931

For instance, a vertex of the ITU-R BT.2020 triangle has the same RGB or YCbCr code as the corresponding vertex in the ITU-R BT-709 triangle but doesn't represent the same color in the CIE 1931 color space.

As color gamuts specified by ITU-R BT.601 and ITU-R BT.709 are quite close, not converting colors between them does not lead to a clearly visible difference of colors. But ITU-R BT.2020 is more than twice larger than ITU-R BT.709:

- Not converting colors from ITU-R BT.709 to ITU-R BT.2020 modifies their X and Y coordinates: there is a gamut "expansion" altering colors that seems more vivid.



Figure 7: Non-conversion from ITU-R BT.709 to ITU-RBT.2020

- At the opposite, not converting from ITU-R BT.2020 to ITU-R BT.709 causes a gamut shrink and some colors (those already in the ITU-R BT.709 triangle) may look washed out.



Figure 8: Non-conversion from ITU-RBT.2020 to ITU-R BT.709

For ITU-R BT.709 to ITU-R BT.2020 conversion, the goal is to calculate the new color codes, so the colors' X&Y values remain unchanged.

For ITU-R BT2020 to ITU-R BT.709 conversion, the main difficulty is to find a compromise between the two following constraints:

- The conversion must calculate the new codes of colors existing in both color spaces, so their X&Y values remain unchanged.
- The conversion must interpolate the value of colors only existing in ITU-R BT2020 (outside ITU-R BT.709 triangle) toward an ITU-R BT.709 color without breaking color gradients too much.

2.2. Why is SDR/HDR conversion needed?

Most of presentation systems claiming to support HDR processing implement a passthrough management: the whole workflow must be homogeneous, and the same dynamic range standard is used from the sources to the display systems.

As soon as one of the contents or displays uses a different standard, some problems appear:

- sources with different dynamic range standards cannot be mixed properly together,
- an output content cannot be displayed properly on a display not supporting its dynamic range.



Figure 9: Non-conversion from SDR (left) to HDR10 (right) leading to burned colors



Figure 10: Non-conversion from HDR10 (left) to HLG (right) leading to dimmed colors

IMPORTANT:

- SDR to HDR conversion does **NOT** improve the colors of an SDR content.
- When properly converted, an SDR content should be displayed on an HDR display identically as it is on an SDR one.

2.3. Why is Color Correction needed?

Some high-end applications require really accurate color rendering and therefore, their displays must be calibrated.

In a nutshell, a dedicated software tool is used to display color test patterns that are measured with a spectrophotometer/colorimeter. Using a device-independent color space (L*a*b* or XYZ for instance), the software can generate an ICC profile of the display and then compute a color correction table.

Another interesting and playful application of correction LUTs is to modify the colors of a video:

- Reduce the number of colors,
- Remap a range of colors to another one (for instance, green becomes orange to turn spring trees into autumn trees)
- Invert colors ...

Color correction look-up tables can be assigned to any input or output of a Livepremier unit.

2.4. Color Keying

An interesting application of look-up table is to map a part of a color space (typically the green colors) to transparency levels and correct color reflection caused by the green screen. It means that for each RGB input triplet of the LUT corresponds a RGBA output quadruplet (RGB + alpha channel).

Thanks to the AW CremaTTe 3D tool (freely available on the Analog Way's website), it is possible to generate a 3D LUT for a LivePremier unit to key an input.

3. The LivePremier Series and its 3D LUT color processing

3.1. Architecture

Updated with firmware v2.0, the LivePremier series was the first generation of presentation systems embedding SDR-HDR converters based on 33x33x33 3D LUTs for <u>all its inputs, images</u> and outputs.

Version 3.0 takes full benefits of this architecture to perform *in real-time and without any* additional latency:

- dynamic range and color space conversions,
- color corrections,
- chroma keying with CremaTTe 3D LUTs (inputs only).

Just like for the frame rate and the internal rate, the sources must be converted to the same color space and dynamic range (called **Internal Profile**) so they can be mixed properly. Then all the outputs can be converted independently to another color space and dynamic range.

By default, the LivePremier series integrates embedded LUTs that are used with the Auto mode settings. Some of these LUTs were developed by the BBC (British Broadcast Corporation) to ensure a high level of accuracy during conversions.

However, it is also possible to use custom LUTs. They must be imported in one of the three LUT libraries depending on their use:

- **Conversion LUTs**: their input/output dynamic ranges and color spaces must be specified to characterize the conversion.
- **Correction LUTs:** their input/output dynamic ranges and color spaces are the same, they change the color mapping.
- **CremaTTe 3D LUTs**: these LUTs must be generated by the AW CremaTTe 3D software.



Figure 11: Dynamic Range et Color Space conversions in the LivePremier Series

M ANALOG WAY®

3.2. Benefits

Working with a LivePremier series switcher eliminates the subsequent drawbacks:

- additional cost of the external converters,
- additional unmanaged latency,
- additional risks of failure (power supplies, cabling...).



Figure 12: Example of heterogeneous workflow with a basic switcher



Figure 13: Example of heterogeneous workflow range setup with a LivePremier system

4. Configuring the color processing

A LivePremier system can be easily configured following these successive steps:

- Configuring the EDID of the inputs
- Configuring the internal processing
- Importing Custom LUTs
- Configuring the inputs
- Configuring the outputs

4.1. Configuring input EDIDs

For HDMI and DisplayPort inputs, configuring the EDID is crucial so that the source delivers its contents with the correct dynamic range.

To indicate the sink supports wide color gamut IUT-R BT.2020, its EDID must contain a CTA-861 extension including a Colorimetry Data Block with the BT2020RG and/or BT2020YCC enabled.

To indicate the sink supports HDR, its EDID must contain a CTA-861 extension including an HDR Static Metadata Data Block.

In LivePremier series, there are four predefined EDIDs indicating the supported types of EOTF (Electro-Optical Transfer Function):

- Perceptual Quantizer (HDR10)
- Hybrid Log-Gamma

These EDIDs are in the *SETUP>EDID* page of the Web RCS. two are for HDMI inputs and the other ones are for DisplayPort inputs.

					Defau	lt EDIDs					
AW1	AQL_DP 3840x2160 60Hz DP UHDTV 60Hz	AW2	AQL_HDMI 3840x2160 60Hz HDMI 2.0 60Hz	AW3	AQL_DP 3840x2160 59.99Hz DP UHDTV 60Hz RB	AW4	AQL_HDMI 3840x2160 59.99Hz HDMI 2.0 60Hz RB	AW5	AQL_DP 1920x1080 60Hz DP 1080p60Hz	AW6	AQL_HDMI 1920x1080 60Hz HDMI 1080p60Hz
AW7	AQL_DP 3840x2160 50Hz DP UHDTV 50Hz	AW8	AQL_HDMI 3840x2160 50Hz HDMI 2.0 50Hz	AW9	AQL_DP 3840x2160 50Hz DP UHDTV 50Hz RB	AW10	AQL_HDMI 3840x2160 50Hz HDMI 2.0 50Hz RB	AW11	AQL_DP 1920x1080 50Hz DP 1080p50Hz	AW12	AQL_HDMI 1920x1080 50Hz HDMI 1080p50Hz
AW13	AQL_DP_HDR 3840x2160 60Hz DP UHDTV 60Hz HDR	AW14	AQL_HDMI_HDR 3840x2160 60Hz HDMI 2.0 60Hz HDR	AW15	AQL_DP 3840x2160 50Hz DP 4K50Hz	AW16	AQL_HDMI 3840x2160 50Hz HDMI 4K50Hz	AW17	AQL_DP 3840x2160 60Hz DP 4K60Hz	AW18	AQL_HDMI 3840x2160 60Hz HDMI 4K60Hz
AW19	AQL_DP_HDR 3840x2160 60Hz DP 4K60Hz HDR	AW20	AQL_HDMI_HDR 3840x2160 60Hz HDMI 4K60Hz HDR	AW21	AQL_HDMI 1920x1080 120Hz HDMI 1080p120Hz	AW22	AQL_DP 1920x1080 120Hz DP 1080p120Hz				

Figure 14: Default EDIDs for HDR support

When an HDMI or DisplayPort source reads such an EDID, it sends InfoFrames to the sink indicating that HDR is enabled, its type etc. Thanks to these InfoFrames, the LivePremier can update its input status. This status is visible in the page *SETUP>Inputs>Input_xx* of the Web RCS.



Figure 15: Status of Input 9 receiving an HDR10 1000nits content

ANALOG WAY®

IMPORTANT: If for any reasons, the sink does not receive InfoFrames from the source, it is still possible to force the dynamic range type. For further details, please refer to the Input configuration chapter 4.4.

4.2. Configuring the internal color processing

As previously said, all inputs must be converted to the same color space and dynamic range to be mixed properly.

These setting are available in the page *SETUP>Preconfig>System* of the Web RCS.

To configure the right Color Space type and Internal Profile, the main sources and displays must be identified. Then they should be set so the minimum number of conversions is necessary for them.

First select the type of the Color Space to use:

- YCbCr 4:4:4 ITU-R BT.709
- YCbCr 4:4:4 ITU-R BT.709 Limited

For SDR setup

- YCbCr 4:4:4 ITU-R BT.2020
- YCbCr 4:4:4 ITU-R BT.2020 Limited

For Wide-gamut SDR or HDR

IMPORTANT: Limited (range) should be used for video sources such as cameras and more usually in the broadcast world whereas Full range are mainly for computer sources.

Then select the Internal Profile:

- SDR
- HDR10
- HLG

IMPORTANT: If HDR10 is selected, a large amount of luminance values is available: the luminance must be selected to the nit level just above the max level of the main sources.

Color Processing				
Туре	YCbCr 4:4:4 ITU-R BT.20	20 Limited▼		
Internal Profile	SDR HDR10 H	ILG		
Luminance	1000 nits	-		

Figure 16: Example of a Color Processing configuration for HDR10

Tip: you can use the input status to get the maximum level of an input (page *SETUP>Inputs>Input_xx* of the Web RCS)

Type	HLG		Type	SMPTE ST2084 (PQ)	
Luma	[0 - 1000] cd/m²		Luma	[0.0005 - 3000] cd/m ²	
Max Content Level	1000 cd/m²		Max Content Level	3000 cd/m ²	
Max Avg Frame Level	250 cd/m²		Max Avg Frame Level	750 cd/m ²	
p0	x: 0.78 y: 0.29		p0	x: 0.78 y: 0.29	
p1	x: 0.17 y: 0.80		p1	x: 0.17 y: 0.80	
p2	x: 0.13 y: 0.05		p2	x: 0.13 y: 0.05	
white	x: 0.31 y: 0.33		white	x: 0.31 y: 0.33	

Figure 17: Example of source statuses

4.3. Importing custom LUTs

For advanced applications, it may be useful to import custom made LUTs into an Aquilon. This can be achieved in the page *SETUP>LUT Libraries* of the Web RCS.

The LivePremier series accepts CUBE files (".cube" extension) as defined by Adobe in "Cube LUT Specification Version 1.0". As this format doesn't include metadata about the input and output, additional information must be set before uploading the file to the Aquilon.

These files can be dragged and drop to the selected slot or chosen via the selection window by clicking on "Update LUT File".



Figure 18: Hovering over an empty slot

4.3.1. Importing conversion LUTs

For Conversion LUTs, information about the input/output properties of the LUT must be set.

Conversion LUT	
SDR2F	IDR10 LUT.cube
UPLOAD LUT	
Label	Enter Label
CONVERT FROM	
Color Space	RGB Limited 🗸
HDR Profile	SDR HDR10 HLG
Luminance	100 nits 🔹
CONVERT TO	
Color Space	RGB Limited (ITU-R BT.2020) 🗸
HDR Profile	SDR HDR10 HLG
Luminance	100 nits 🔹
	Upload

Figure 19: Upload form for a conversion LUT

Once the LUT is uploaded, it appears in the library with its properties. At the bottom right part of the slot, a small indicator shows if the LUT is currently being used.



Figure 20: Slot of a conversion LUT after upload

4.3.2. Importing correction LUTs

For Correction LUTs, the color space used by the LUT must be set.



Figure 21: Upload form for a correction LUT



Figure 22: Slot of a correction LUT after upload

Once the LUT is uploaded, it appears in the library with its properties. At the bottom right part of the slot, a small indicator shows if the LUT is currently being used.

4.3.3. Importing CremaTTe 3D LUTs

For CremaTTe 3D LUTs, the color space used by the LUT must be set.



Figure 23: Upload form for a CremaTTe 3D LUT

IMPORTANT: Please note that CremaTTe 3D LUTs can be directly generated and imported to the selected slot using the AW CremaTTe 3D software.

CremaTTe 3D LUT	
💮 CremaTTe 3D LUT 🚯 📩	0
Green Screen Keying	
Color Space	
RGB Limited	
	•

Figure 24: Slot of a CremaTTe 3D LUT after Upload

4.4. Configuring the conversions for inputs

The HDR settings of the inputs are available in the *Group Signal* tab of the Web RCS page *SETUP>Inputs>Input_xx*.

By default, all the settings are configured in AUTO mode. In this mode, all the input settings are automatically computed to create a consistent workflow in terms of color space and dynamic range. Embedded LUTs are used (some created by the BBC, some created by Analog Way).

However, it may happen that the InfoFrames are not sent properly by the source. Therefore, the input settings allow to override the status.

Group Signal	Group Pattern	Group Adjustmen	nts Group Aspect Gro
6 Modifying the	se settings impacts t	hose of all the inputs	of the group.
Settings			
Туре	Auto	•	
Dynamic Range	AUTO SD	R HDR10 HLG	i
HDCP	Default	•	
Conversion Mode			
Mode	AUTO LU	т	

Figure 25: Forcing the dynamic range of an input

When selecting "LUT" in the section "Conversion Mode" of the tab, it is also possible to use a Custom LUT form the conversion LUT library instead of the predefined one.

Conversion Mode		
Mode	AUTO LUT	
Conversion LUT		
Conversion LUT	1 SDR to HDR10 LUT	•

Figure 26: Selecting an input custom conversion LUT

IMPORTANT: For each input, the list of available LUTs is filtered depending on their compatibility with the input properties and the internal processing.

Input	Settings			
Profile				
SDR	No settings as no conversion.			
	Luminance: to help the system to apply the most efficient LUT, the closest			
	value above the input luminance level must be selected among:			
	- 100 nits - 700 nits - 1800 nits - 7000 nits			
	- 200 nits - 800 nits - 2000 nits - 8000 nits			
HDR10	- 300 nits - 1000 nits - 3000 nits - 9000 nits			
	- 400 nits - 1200 nits - 4000 nits - 10000 nits			
	- 500nits - 1400 nits - 5000 nits			
	- 600 nits - 1600 nits - 6000 nits			
HLG BBC	BBC Reference: depending on the content type, the conversion will also be different. Two types are available: - Scene referred: Input is a camera or a graphic with camera image. - Display referred: Input is a graded content or graphics. BBC OETF: if the reference type is Scene referred, two types of OETF are available, and this setting must be chosen according to the camera			
	- Square Root.			
	- Strict (BT.709).			

4.4.1. Configuring the inputs with an SDR internal processing

4.4.2. Configuring the inputs with an HDR10 internal processing

Input Profile	Settings
	Luminance : to help the system to apply the most efficient LUT so that the
	white level of the SDR content is not too bright leading to burned content,
	two values are available:
SDR	- 100 nits: standard luminance of SDR.
	- 200nits: ITU-R BT.2408-3 recommends around 58% of the PQ
	level, this corresponds to a 200nit luma level.
	IMPORTANT : SDR \rightarrow HDR10 \rightarrow SDR conversion may alter the colors
HDR10	No settings: as PQ scale uses an absolute scale.
HLG BBC	No settings: luminance is automatically forced to 1000 nits.

Input Profile	Settings
	 BBC Mapping: when converting SDR to HLG, pixels must be converted from the BT.601 / BT.709 color spaces to BT.2020 color space. This operation can be configured either as: Inverse Tone Mapping: conversion output is extended to - 5%/+105%. This setting must only be used when the input color space and the internal color space have a limited range. Direct Mapping: each color of the input color space remains the same one.
SDR	 BBC Reference: depending on the content type, two conversion types are available: Scene referred: Input is a camera or a graphic with camera image. Display referred: Input is a graded content or graphics.
	BBC OETF : if the reference type is Scene referred, two types of Opto- Electric Transfer Function are available, and this setting must be chosen according to the camera specifications between the two values: - Square Root - Strict (BT.709)
HDR10	LuminanceLuminanceto help the system to apply the most efficient LUT, the closestvalue above the input luminance level must be selected among:- 100 nits- 700 nits- 1800 nits- 7000 nits- 200 nits- 800 nits- 2000 nits- 8000 nits- 8000 nits- 300 nits- 1000 nits- 3000 nits- 9000 nits- 9000 nits- 400 nits- 1200 nits- 4000 nits- 10000 nits- 500nits- 1400 nits- 5000 nits- 6000 nits
HLG BBC	No settings as no conversion.

4.4.3. Configuring the inputs with an HLG BBC internal processing

4.5. Configuring the color correction LUT for inputs

The color correction settings of the inputs are available in the *Group Adjustments* tab of the Web RCS page *SETUP>Input_xx*.

The LUT mode must be selected and the LUT must be chosen in the dropdown list.

IMPORTANT: For each input, the list of available LUTs is filtered depending on their compatibility with the input properties.

Group Signal	Group Pattern	Group Adjustments	Group				
Modifying these	se settings impacts	those of all the inputs of th	e group.				
Correction							
Mode	MANUAL	LUT					
Brightness				Group Signal	Group Pattern	Group Adjustments	Group
Global	0			A Modifying the		those of all the inputs of the	e group
Red Component	0				se secongs impores		- group.
Green Componen	t 0			Correction			
Blue Component	0			Mode	MANUAL	LUT	
				Correction LUT			
Contrast				Correction LUT	2 Over satu	irates the colors 💌	
Global	0						
Red Component	0			Sharpness			
Green Componen	t 0			Level	Low Med	dium High	
Blue Component	0						
Colorimetry							
Saturation	0						
Hue	0						
Sharpness							
Level	Low Me	dium High					

Figure 27: Standard manual color correction (left) vs LUT-based color correction (right)

IMPORTANT: Please note that both modes are exclusive and cannot be cumulated.

4.6. Configuring the CremaTTe 3D LUT for inputs

The CremaTTE 3D LUT to key an input can be generated using the AW CremaTTe 3D tool. In the software's connection wizard, after connecting to the Aquilon, the input and the LUT library slot must be chosen.

M Connection Wizard	1 ? X
STEP 1	
Connection to the	hardware
192, 168, 4, 58	Connect
STEP 2	
Choose physical in	put to process
Input 1	▼
Choose Crematte	BD LUT Slot in library
Slot 2	v
Apply	and go
SYNCLUT	CONNECTED
Disconnect	Reset Wizard

Figure 28: Connection wizard of AW CremaTTe 3D

The CremaTTe 3D settings of the inputs are available in the *Group Keying* tab of the Web RCS page *SETUP>Inputs>Input_xx*.

Group Si	gnal Gr	oup Pattern	Group /	Adjustments	Group As	spect	Group Keying
6 Modit	ying these set	ttings impacts	those of all	the inputs of	f the group.		
Keying							
Mode		Disabled	Chroma	Luma	CremaTTe 3D		
CremaTT	e 3D LUT						
CremaT	fe 3D LUT	1 Keying Ir	nput 1	-			
Mask							
Value		None	Black and W	/hite Col	or		

Figure 29: LUT selection for input keying

IMPORTANT: CremaTTe 3D keying only works in an SDR workflow.

4.7. Configuring the conversions for outputs

The HDR settings of the outputs are available in the *Signal* tab of the Web RCS page *SETUP>Outputs>Output_xx*.

By default, all the settings are configured in AUTO mode. In this mode, all the output settings are automatically computed using the EDID status of the output device and the internal profile. Embedded LUTs are used (some created by the BBC, some created by Analog Way). However, it is possible to force the configuration of an output using its settings.

Group Format	Group Patte	ern Sig	nal	Adjustments
Settings				
Pixel Encoding	Auto			-
Color Space	Auto	ITU-R BT.70	9 ITU-	R BT.2020
Dynamic Range	AUTO	SDR HI	DR10	HLG
HDCP	Auto			-
DVI Mode	OFF			
DDC Bus Speed	Slow	Medium	Fast	
Conversion Mode				
Mode	AUTO	LUT		

Figure 30: Forcing the color space and dynamic range of an output

When selecting "LUT" in the section "Conversion Mode" of the tab, it is also possible to use a Custom LUT form the conversion LUT library instead of the predefined one.

Conversion Mode		
Mode	AUTO LUT	
Conversion LUT		
Conversion LUT	3 HLG to HDR10	-

Figure 31: Selecting an output custom conversion LUT

IMPORTANT: For each output, the list of available LUTs is filtered depending on their compatibility with the output settings and the internal processing.

4.7.1. Configuring the outputs with an 5DN internal processin	4.7.1. Configurir	ng the output:	s with an SDR	internal	processing
---	-------------------	----------------	---------------	----------	------------

Output Profile	Settings
SDR	No settings as no conversion.
	Luminance : to help the system to apply the most efficient LUT and send the proper InfoFrame, two values are available:
HDR10	 100 nits: standard luminance of SDR.
	 200nits: ITU-R BT.2408-3 recommends around 58% of the PQ level, this corresponds to a 200nit luma level.
	BBC Mapping: when converting SDR to HLG, pixels must be converted
	from the BT.601 and BT.709 color spaces to BT.2020 color space. This
	operation can be configured either as:
	 Inverse Tone Mapping: the output of the conversion is extended to -5%/+105%. This setting must only be used when the output color space and the internal color space have a limited range. Direct Mapping: each color of the output color space stays the same one.
HLG BBC	<u>BBC Reference</u> : depending on the content type, the conversion will also be different. Two types are available:
	 Scene referred: Input is a camera or a graphic with camera image.
	- Display referred : Input is a graded content or graphics.
	 BBC OETF: this setting is only available if the reference type is Scene referred. Two types of OETF are available, and this setting must be chosen according to the camera specifications between two values: Square Root. Strict (BT.709) (recommended).

4.7.1. Configuring the outputs with an HDR10 internal processing

Output Profile	Settings
	No settings: the system automatically selects the best LUT according to
SDK	the internal processing nit level.
	No settings: as PQ uses an absolute scale. The output sends a Luminance
HDRIU	InfoFrame based on the Internal Profile Luminance.
	No settings: the system automatically selects the best LUT according to
	the internal processing nit level.

Output Profile	Settings
	BBC Reference: depending on the content type, the conversion will also
	be different. Two types are available:
	- Scene referred: Input is a camera or a graphic with camera
	image.
	- Display referred : Input is a graded content or graphics.
SDR	
	<u>BBC OETF</u> : if the reference type is Scene referred. Two types of OETF are
	available, and this setting must be chosen according to the camera
	specifications between the two values:
	- Square Root
	- Strict (BT.709)
HDR10	No settings: the Luminance InfoFrame is automatically forced to 1000 nits.
HLG BBC	No settings as no conversion.

4.7.2. Configuring the outputs with an HLG BBC internal processing

4.8. Configuring the color correction LUT for outputs

The color correction settings of the outputs are available in the *Adjustments* tab of the Web RCS page *SETUP>Outputs>Output_xx*.

The LUT mode must be selected and the LUT must be chosen in the dropdown list.

IMPORTANT: the list of available LUTs is filtered depending on their compatibility with the output properties.

rection Mode MANUAL UT Brightness Global Gene Component G Gene Component G Gen Gen Gen Gen Gen Gen Gen Gen Gen G	Group Format	Group Pattern	Signal	Adjustments		
Mode MANUAL LUT Brightness Global 0 Red Component 0 0 0 Blue Component 0 0 0 Global 0 Blue Component 0 0 0 Global 0 Red Component 0 0 0 Global 0 Red Component 0 0 0 Green Component 0 0 0 Blue Component 0 0 0 Global 0 Blue Component 0 0 0 1 0 1 0 1 0 1 0 1 0	Correction					
Brightness Global 0 Red Component 0 Global 0 Green Component 0 Global 0 Contrast 0 Global 0 Sturation 0 Global 0# Yolue 0# Global 0# Global 0# Global 0# Global 0# Yolue 0#	Mode	MANUAL	LUT			
Global 0 Red Component 0 Green Component 0 Blue Component 0 Global 0 Contrast 0 Global 0 Global 0 Global 0 Global 0 Group Format Group Pattern Correction Mode Mode MANUAL Green Component 0 Green Component 0 Green Component 0 Blue Component 0 Saturation 0 Hue 0 Temperature 6500 Guota 6500 Gamma 1	Brightness					
Red Component 0 Green Component 0 Blue Component 0 Global 0 Red Component 0 Global 0 Red Component 0 Green Component 0 Blue Component 0 Blue Component 0 Green Component 0 Blue Component 0 Green Component 0 Blue Component 0 O 0 Saturation 0 Green Component 0 O 0 Saturation 0 OFF 0 Yalue 0 Goog 0 Ganma 1	Global	0				
Green Component 0 Blue Component 0 Contrast Group Format Group Pattern Global 0 Mode MANUAL Red Component 0 Correction LUT Correction LUT 1 Over satur Global 0 0 1 Over satur Blue Component 0 0 0 0 Gotorimetry 0 0 0 0 0 0 Saturation 0	Red Component	0				
Blue Component 0 Contrast 0 Global 0 Red Component 0 Green Component 0 Blue Component 0 O 0 Saturation 0 Hue 0 Saturation 0 Perperature 6500 Granna 6500 Level 1	Green Component	0				
Contrast Global 0 Red Component 0 Green Component 0 Blue Component 0 Correction LUT Correction LUT 1 Over saturation Hue 0 Enable OFF Value 6500 Comma Level 1	Blue Component	0				
Global 0 Red Component 0 Green Component 0 Blue Component 0 Blue Component 0 Colorimetry 0 Saturation 0 Hue 0 Temperature Enable Off Value 6500 Gamma Level 1	Contract				Group Format	Group Pattern
Global 0 Red Component 0 Green Component 0 Blue Component 0 O 0 Colorimetry 0 Saturation 0 Hue 0 O 0 Temperature 0 Value OFF Solo 0 Gamma 1					Correction	
Red Component 0 Green Component 0 Blue Component 0 Olorimetry 0 Saturation 0 Hue 0 O 0 Temperature Enable OFF Value 0 6500 Level 1	Global	0			Mode	MANUAL
Green Component 0 Blue Component 0 Colorimetry 0 Saturation 0 Hue 0 Temperature Enable OFF Value 0500 Gamma Level 1	Red Component	0			Correction LUT	
Blue Component 0 Colorimetry Saturation Hue 0 Temperature Enable OFF Value 6500 Gamma Level 1	Green Component	0			Correction LUT	1 Over satur
Colorimetry Saturation 0 Hue 0 Temperature Enable OFF Value 0500 Gamma Level 1	Blue Component	0				l over sutur
Saturation0Hue0TemperatureEnableOFFValueOFFGammaLevel1	Colorimetry					
Hue0TemperatureEnableOFFValue6500GammaLevel1	Saturation	0				
Temperature Chable OFF Value 6500 Gamma Level 1	Hue	0				
Enable OFF Value 6500 Gamma	Temperature					
Level 1						
Gamma Level 1	Enable	OFF				
Gamma Level 1	value	6500				
Level 1	Gamma					
	Level	1				

Figure 32: Standard manual color correction (left) vs LUT-based color correction (right)

IMPORTANT: Please note that both correction modes are exclusive and cannot be cumulated.

4.9. Configuring an output connected to a DPH104

When a DPH104 is connected to an output of an Aquilon, the DPH104 presents an input EDID that is totally independent from the displays connected to its outputs. DPH104's EDID supports 4K formats and HDR contents (HDR10 and HLG).



Figure 33: No link between displays' EDIDs and DPH104's EDID

Therefore, if the internal profile of the LivePremier system is HDR10 or HLG, the output connected to the DPH104 will deliver HDR content when its HDR Output Profile is configured as "Auto".

If non-HDR displays are connected to the DPH104 outputs and the Aquilon's internal profile is HDR10 or HLG, then the Output Profile of the output connected to the DPH104 must be forced to SDR.